







1




2.



1.




0°




180°


3




4







5







7








9





Montážny návod noha lav.

L071x brožúra

Z1580000233

